

## STIHL - 11100849102 - Guía de cuerda de arranque

Recambio original para las siguientes máquinas STIHL:

MS150C-E | MS150TC-E | MS151TC-E | MS151C-E | MS162 | MS162C-BE | MS170 | MS170-D | MS1702-MIX | MS170C-ED | MS171 | MS172 | MS172C-BE | MS180 | MS180C-B | MS180C-BD | MS1802-MIX | MS180C-BE | MS181 | MS181C-BE | MS182 | MS182C-BE | MS190T | MS192C-E | MS192T | MS192TC-E | MS193C-E | MS193T | MS193TC-E | MS194C-E | MS194T | MS194TC-E | MS200 | MS200T | MS201 | MS201C-M | MS201T | MS201TC-M | MS210 | MS210C-BE | MS211 | MS211C-BE | MS212 | MS212C-BE | MS230 | MS230C-B | MS230C-BE | MS231 | MS231C-BE | MS251 | MS251C-BE | MS240 | MS241C-M | MS250 | MS250C-BE | MS260 | MS260C-B | MS260-D | MS261 | MS261C-BE | MS261C-Q | MS261C-M | MS261C-BM | MS261C-MQ | MS270 | MS270C-B | MS280 | MS271 | MS271C-BE | MS291 | MS291C-BE | MS290 | MS310 | MS311 | MS341 | MS360 | MS360C | MS361 | MS362 | MS362C-M | MS380 | MS390 | MS391 | MS400C-M | MS440 | MS441 | MS441C-M | MS460 | MS460-ZMagnum | MS460-R | MS461 | MS461-R | MS462C-M | MS462C-MR Rettungssäge | MS500i | MS640 | MS650 | MS660 | MS660-W | MS661C-M | MS880 | MS881 | 9 | 009Q | 009LQ | 009EQ | 009E | 010AV | 011AVE | 011AVEQ | 010AVEQ | 012AVEQ | 012AVTEQ | 17 | 017C | 18 | 018C | 019T | 020(1114) | 020T | 21 | 23 | 023L | 25 | 24 | 024S | 024SW | 024SWVH | 26 | 026W | 026WVH | 026C | 028Q | 28 | 028W | 028WB | 29 | 39 | 31 | 032AV | 032AVE | 032AVEQ | 032AVEW | 032AVEQW | 032AVQ | 34 | 034S | 036BR | 36 | 036W | 036Arctic | 036WVH | 038FB | 38 | 038W | 038S | 038SW | 038M | 038MW | 038MR II | 041AVEQ | 041AVQ | 041AVFBQ | 041FB | 041G | 042Q | 42 | 44 | 044W | 044C | 045AV | 045AVE | 045AVEQ | 045AVSE | 045AVSEQ | 046C | 46 | 046W | 046MagnumBR | 046WVH | 048W | 048AV | 048AVE | 48 | 51 | 051Q | 56 | 056S | 056M | 064W | 64 | 064R | 66 | 066W | 066M | 066MR | 066BR | 70 | 075AVEQ | 075AVE | 076S | 08SE | 84 | 084W | 084R | 88 | 090AV | 90 | 090G | FS120R2-MIX | FS1202-MIX | FS120 | FS120R | FS200 | FS200R | FS250 | FS160 | FS180 | FS220 | FS220K | FS280 | FS280K | FS240C-E | FS240RC-E | FS260C-E | FS260 | FS261C-E | FS200 | FS202 | FS300 | FS350 | FS360-4116 | FS420 | FS360C-E-4147 | FS410C-E | FS360C-EM-4147 | FS410C-EM | FS450 | FS400-K | FS400 | FS450-K | FS480 | FS410(4110) | FS411C-EM | FS460C-EM | FS461C-EM | FS490C-EM | FS491C-EM | FS510C-EM | FS511C-EM | FS560C-EM | FS561C-EM | FS500 | FS550 | FS550-L | FR350 | FR450 | FR480(4128) | FR410C-E | FR460TC-EM | FR460TC-EFM | SP200 | SP400 | SP450 | SP451 | SP481 | SP452 | SP471 | SP482 | MC200 | SR320 | SR400 | SR340 | SR420 | SR430 | SR450 | TS08S | TS350 | TS350AVE | TS400 | TS410 | TS420 | TS420-A | TS440-A | TS460 | TS500i-A | TS760 | TS700 | TS800 | GS461 | BT120C | BT121 | BT360 | P835 | P840 | BR320 | BR400 | BR340 | BR420 | BR380 | BR430 | BR450 | BR450C-EF | BR500 | BR550 | BR600 | BR700

Tipos de máquina: Motosierra, Desbrozadora, Tronzadora, Vareadora, Sopladora, Ahoyadora

Referencias OEM STIHL: 11100849102, 1110 084 9102, 1110-084-9102

Referencias alternativas STIHL: 11100849100, 1110 084 9100, 1110-084-9100

Denominaciones STIHL: Guía, Casquillo

Modelos de STIHL: MS 150 C-E, MS 150 TC-E, MS 151 TC-E, MS 151 C-E, MS 162, MS 162 C-BE, MS 170, MS 170-D, MS 170 2-MIX, MS 170 C-E D, MS 171, MS 172, MS 172 C-BE, MS 180, MS 180 C-B, MS

180 C-B D, MS 180 2-MIX, MS 180 C-BE, MS 181, MS 181 C-BE, MS 182, MS 182 C-BE, MS 190 T, MS 192 C-E, MS 192 T, MS 192 TC-E, MS 193 C-E, MS 193 T, MS 193 TC-E, MS 194 C-E, MS 194 T, MS 194 TC-E, MS 200, MS 200 T, MS 201, MS 201 C-M, MS 201 T, MS 201 TC-M, MS 210, MS 210 C-BE, MS 211, MS 211 C-BE, MS 212, MS 212 C-BE, MS 230, MS 230 C-B, MS 230 C-BE, MS 231, MS 231 C-BE, MS 251, MS 251 C-BE, MS 240, MS 241 C-M, MS 250, MS 250 C-BE, MS 260, MS 260 C-B, MS 260-D, MS 261, MS 261 C-BE, MS 261 C-Q, MS 261 C-M, MS 261 C-BM, MS 261 C-MQ, MS 270, MS 270 C-B, MS 280, MS 271, MS 271 C-BE, MS 291, MS 291 C-BE, MS 290, MS 310, MS 311, MS 341, MS 360, MS 360 C, MS 361, MS 362, MS 362 C-M, MS 380, MS 390, MS 391, MS 400 C-M, MS 440, MS 441, MS 441 C-M, MS 460, MS 460-Z Magnum, MS 460-R, MS 461, MS 461-R, MS 462 C-M, MS 462 C-M R Rettungssäge, MS 500i, MS 640, MS 650, MS 660, MS 660-W, MS 661 C-M, MS 880, MS 881, 9, 009 Q, 009 LQ, 009 EQ, 009 E, 010 AV, 011 AVE, 011 AVEQ, 010 AVEQ, 012 AVEQ, 012 AVTEQ, 17, 017 C, 18, 018 C, 019 T, 020 (1114), 020 T, 21, 23, 023 L, 25, 24, 024 S, 024 SW, 024 SWVH, 26, 026 W, 026 WVH, 026 C, 028 Q, 28, 028 W, 028 WB, 29, 39, 31, 032 AV, 032 AVE, 032 AVEQ, 032 AVEW, 032 AVEQW, 032 AVQ, 34, 034 S, 036 BR, 36, 036 W, 036 Arctic, 036 WVH, 038 FB, 38, 038 W, 038 S, 038 SW, 038 M, 038 MW, 038 MR II, 041 AVEQ, 041 AVQ, 041 AVFBQ, 041 FB, 041 G, 042 Q, 42, 44, 044 W, 044 C, 045 AV, 045 AVE, 045 AVEQ, 045 AVSE, 045 AVSEQ, 046 C, 46, 046 W, 046 Magnum BR, 046 WVH, 048 W, 048 AV, 048 AVE, 48, 51, 051 Q, 56, 056 S, 056 M, 064 W, 64, 064 R, 66, 066 W, 066 M, 066 MR, 066 BR, 70, 075 AVEQ, 075 AVE, 076 S, 08 SE, 84, 084 W, 084 R, 88, 090 AV, 90, 090 G, FS 120 R 2-MIX, FS 120 2-MIX, FS 120, FS 120 R, FS 200, FS 200 R, FS 250, FS 160, FS 180, FS 220, FS 220 K, FS 280, FS 280 K, FS 240 C-E, FS 240 RC-E, FS 260 C-E, FS 260, FS 261 C-E, FS 200, FS 202, FS 300, FS 350, FS 360 - 4116, FS 420, FS 360 C-E - 4147, FS 410 C-E, FS 360 C-EM - 4147, FS 410 C-EM, FS 450, FS 400-K, FS 400, FS 450-K, FS 480, FS 410 (4110), FS 411 C-EM, FS 460 C-EM, FS 461 C-EM, FS 490 C-EM, FS 491 C-EM, FS 510 C-EM, FS 511 C-EM, FS 560 C-EM, FS 561 C-EM, FS 500, FS 550, FS 550-L, FR 350, FR 450, FR 480 (4128), FR 410 C-E, FR 460 TC-EM, FR 460 TC-EFM, SP 200, SP 400, SP 450, SP 451, SP 481, SP 452, SP 471, SP 482, MC 200, SR 320, SR 400, SR 340, SR 420, SR 430, SR 450, TS 08 S, TS 350, TS 350 AVE, TS 400, TS 410, TS 420, TS 420-A, TS 440-A, TS 460, TS 500i-A, TS 760, TS 700, TS 800, GS 461, BT 120 C, BT 121, BT 360, P 835, P 840, BR 320, BR 400, BR 340, BR 420, BR 380, BR 430, BR 450, BR 450 C-EF, BR 500, BR 550, BR 600, BR 700

Tipo de recambio: Original OEM

Fabricante: STIHL

Unidad de venta: 1

