

STIHL - 41471419802 - Boquilla botón accionamiento aire desbrozadora STIHL

FS360C, FS361C, FS410C, FS411C, FS460C, FS461C, FR460TC

Recambio original para las siguientes máquinas STIHL:

FR460TC-EFM | FR460TC-EM | FS360C-EM-4147 | FS361C-EM | FS361.0C-EM | FS410C-EM | FS411C-EM | FS411.0C-EM | FS460C-EM | FS461C-EM | FS461.0C-EM

Tipo de máquina: Desbrozadora

Referencias OEM STIHL: 41471419802, 4147 141 9802, 4147-141-9802

Referencias alternativas STIHL: 41471419801, 4147 141 9801, 4147-141-9801

Denominaciones STIHL: Boquilla, Tapa

Modelo de STIHL: FR 460 TC-EFM, FR 460 TC-EM, FS 360 C-EM - 4147, FS 361 C-EM, FS 361.0 C-EM, FS 410 C-EM, FS 411 C-EM, FS 411.0 C-EM, FS 460 C-EM, FS 461 C-EM, FS 461.0 C-EM

Tipo de recambio: Original OEM

Fabricante: STIHL





