

STIHL - 11301412300 - Cierre de la cubierta de motor motosierra STIHL

017, 018, 024, 026, 034, 036, 017C, 018C, 024S, 026C, 026W, 034AV, 034S, 036W, MS170, MS170C, MS180, MS180C, MS240, MS260, MS260C, MS360, MS360C

Recambio original para las siguientes máquinas STIHL:

017 | 018 | 024 | 026 | 034 | 036 | 017C | 018C | 024S | 026C | 026W | 034AV | 034FB | 034S | 036Arctic | 036BR | 036W | MS170 | MS170C-ED | MS180 | MS1802-MIX | MS180C-B | MS180C-BD | MS180C-BE | MS240 | MS260 | MS260C-B | MS260-D | MS360 | MS360C

Tipo de máquina: Motosierra

Referencias OEM STIHL: 11301412300, 1130 141 2300, 1130-141-2300

Denominaciones STIHL: Cierre capot, Botón, Broche

Modelo de STIHL: 017, 018, 024, 026, 034, 036, 017 C, 018 C, 024 S, 026 C, 026 W, 034 AV, 034 FB, 034 S, 036 Arctic, 036 BR, 036 W, MS 170, MS 170 C-E D, MS 180, MS 180 2-MIX, MS 180 C-B, MS 180 C-B D, MS 180 C-BE, MS 240, MS 260, MS 260 C-B, MS 260-D, MS 360, MS 360 C

Tipo de recambio: Original OEM

Fabricante: STIHL





